

Belle Meeting Chair.

User Guide



1. Seat Height

While seated, pull on the right hand side lever to lower the seat. Support your own weight off the seat while lifting the lever to raise the height.

2. Seat Tilt

To release the tilt mechanism pull on the left hand side lever once. To lock the tilt mechanism pull once more on the left hand side lever.

AWM

**AWM
AMARO**