

Mera Flip Table.

User Guide



Flipping the Top

1. To flip the top, pull the bar towards the front edge of the table top with both hands to unlock the top.
2. Lift upwards to flip the top until it clicks into place in an upright position.
3. To lower the top, lift the bar upwards with both hands to unlock the top, before lowering the tabletop until it locks in the down position.

