


Jetson Meeting Chair

Seat Tilt Adjustment

To activate the seat tilt, pull the left hand side paddle to unlock and adjust to the comfortable position. To deactivate the adjustment, pull the handle again to lock in the desired position.

Seat Height

While seated, pull outward the right hand side paddle to lower the seat. Support your own weight off the seat while pulling the paddle to raise the height.



**AWM.
AMAROO**
User Guide

