Camilla Task Chair.

User Guide



1. Backrest Tension

Turn the knob on the right hand side of the seat to adjust the tension of the backrest.

2. Seat Height

While seated, lift the right hand side paddle to lower the seat. Support your own weight off the seat while lifting the paddle to raise the height.

3. Backrest Tilt

To prevent the backrest from tilting, push the lever on the left hand side towards the floor. To unlock the tilt mechanism, lift the lever upwards.

4. Seat Depth

While seated, pull the lever located under the seat on the left hand side and slide the seat forwards or backwards, release the paddle to lock the seat pan at the desired depth.

5. Lumbar Support

The lumbar support is simply slid up or down to suit the location of the small of your back.

6. Armrest Height (If Applicable)

To change the height of the armrest, push and hold the button and slide each armrest up or down.

