

# Path Task Chair

## Humanscale®



### Recline Tension

Liberty utilises a sophisticated mechanism that automatically adjusts recline tension to match your body weight. To set recline tension, all you have to do is sit.

#### 1. Seat Height

Lift up on lever and position chair to a comfortable height, with your thighs parallel to the floor and your feet fully supported by the floor. Release lever.

#### 2. Armrest Height

Depress button on underside of armrest. Reposition armrest to desired height and release.

#### 3. Seat Depth

Pull out on lever on the side of the seat to a position such that when you're sitting with your back fully against the backrest, there are 50-100mm of clearance between the front edge of the seat and the back of your knee. Release lever.

**AWM**

**AWM  
AMARO**