

Liberty Drafting Chair.

User Guide



Recline Tension

Liberty utilises a sophisticated mechanism that automatically adjusts recline tension to match your body weight. To set recline tension, all you have to do is sit.

1. Seat Height

While seated, lift the right hand side paddle to lower the seat. Support your own weight off the seat while lifting the paddle to raise the height.

2. Seat Depth

Lift up the lever under the forward edge of the seat and slide the seat to the desired position, release the lever to lock the seat.

3. Armrest Height

To change the height of the armrests, press and hold the button and slide each armrest up or down. Release the button at the desired height.

4. Footring Height

Turn the footring anti-clockwise to unlock before raising or lowering it to the desired height. Press down on the plastic cap to the top of the footring and turn the ring clockwise to lock in position.